

MODEL : K220VO



Image provided for illustrative purposes only

Power Rating		
Standby power LTP	kVA	220,0
Prime power PRP	kVA	202,7

Main Features		
Frequency	Hz	50
Voltage	V	400/230V
Power factor	cos ϕ	0,8
Phase and connection		3

Main Specifications		
Engine Make & Model	Volvo	TAD733GE
Speed Governor		Electronic
Alternator Make & Model	Mecc Alte	ECO38-2SN/4
Fuel Tank (ltrs) / Autonomy @75% load (hrs)	400	11
Noise Level - dB(A) @7mt		0
Dimensions	L x W x H (mm)	2650x1180x1860
Weight	Kg	2026

General Structure

BASE FRAME MADE OF WELDED STEEL PROFILE, COMPLETE WITH:

- Steel base frame with support legs
- Anti-vibration mountings properly sized
- Grounding point to connect all metal parts of the generating set

FUEL TANK WITH THE FOLLOWING COMPONENT:

- Filler neck
- Air breather (ventilation pipe)
- Minimum fuel level sensor

PROTECTIONS:

- Moving and rotating parts protection against accidental contacts.

ENGINE COMPLETE WITH:

- Battery
- Liquids (no fuel)

EXHAUST (Standard):

- Industrial silencer (loose)

TECHNICAL DATA SHEET

Engine		
Brand		Volvo
Model		TAD733GE
Speed Governor		Electronic
Max power PRP	kW	181
R.P.M.		1500
Cylinders		6 in line
Displacement	cm ³	7150
Fuel consumption at 75% of load	l/h	34,9
Cooling System		Water
Aspiration		Turbocharged-intercooled

ALTERNATOR		
Brand		Mecc Alte
Model		ECO38-2SN/4
Pole		4
Stator/rotator insulation		H
Protection level	IP	23

PHYSICAL CHARACTERISTICS		
Integrated fuel tank	LTR	400
Lead acid batteries		24V140AH
Dimensions	L x W x H (mm)	2650x1180x1860
Weight	Kg	2026

Noise Level dB(A) LWA		
Guaranteed Noise Level	dB(A) LWA	0
Noise Pressure Level	@ 7 mt	0

MCP - Manual control panel

Mounted on the genset and complete of: instrumentation, control, protection of the generating set.

INSTRUMENTATION (ANALOGUE)

- Voltmeter (1 phase)
- Ammeter (1 phase)
- Hours-counter

COMMANDS

- Start/stop selector switch with key (Glow plugs preheating function also included).
- Emergency stop button

PROTECTION WITH ALARM

- Low fuel level
- Battery charger failure
 - low oil pressure
- high engine temperature
 - Earth Fault.

- Low fuel level
- Battery charger failure
 - low oil pressure
- high engine temperature.
- Circuit breaker protection: III poles
 - Emergency stop button

OUT PUT PANEL MCP

Power cables connection to Circuit Breaker.



ACP - Automatic control panel

Mounted on the genset, complete with digital control unit AC03 for monitoring, control and protection of the generating set, protected through door with lockable handle.

COMMANDS AND OTHERS

- Four operation modes: OFF - Manual starting - Automatic starting - Automatic test.
- Push-button for forcing Mains contactor or Genset contactor.
- Push-buttons: start/stop, fault reset, up/down/page/enter selection.
- Remote starting availability.
- DC system disconnection switch.
- Acoustic alarm.
- Automatic battery charger.
- RS232 Communication port.
- Settable PASSWORD for protection level.

ALARM PROTECTION

- Engine protection: low fuel level, low oil pressure, high engine temperature.
- Genset protection: under/over voltage, overload, under/over frequency, starting failure, under/over battery voltage

SHUT DOWN PROTECTION

- Engine protection: low fuel level, low oil pressure, high engine temperature,
- Genset protection: under/over voltage, overload, under/over battery voltage, battery charger failure.
- Circuit breaker protection: III poles.
- Earth Fault included in the control unit.

OTHERS PROTECTION

- Emergency stop button.
- Panel protected through door with lockable handle.

OUTPUT PANEL ACP

Plinth row for connection from ACP to LTS panel.
 Power cables connection to Circuit Breaker.



LTS - LOAD TRANSFER SWITCH - Accessories ACP

Nominal Current	A	315
Width (W)	mm	800
Height (H)	mm	600
Depth (D)	mm	300